USER MANUAL

GLASS DOOR FOR WINE CELLAR

VINORAGE™

Your wine cellar/glass door is manufactured by:

Vinorage ApS
Terndrupvej 69
DK-9460 Brovst

CE

THANK YOU FOR PURCHASING A VINORAGE GLASS DOOR.

PLEASE READ THE ENTIRE MANUAL AND THE SAFETY INSTRUCTIONS CAREFULLY BEFORE USING YOUR VINORAGE WINE CELLAR/GLASS DOOR.

USING THE GLASS DOOR

When installing your Vinorage wine cellar and/or mounting the Vinorage glass door, a low-voltage control switch will be mounted on your wall.

One row of switches is used to open and close the door to the wine cellar.



MAINTENANCE

The only maintenance required is regular cleaning. We recommend using a suitable detergent and a microfiber cloth for stainless steel and glass. Do not use metal scouring pads, steel wool, or metal brushes.

SAFETY

When opening or closing the glass door, always ensure that no one is standing near the door. Be extra careful if there are small children in the home. They will probably find the automatic door exciting. We recommend a safety distance of at least 50 cm from the edge of the door.

Never leave your wine cellar open after use, as there is a risk that visually impaired or curious children could fall in and injure themselves.

Never allow children to use, play or climb in the wine cellar.

ENJOY YOUR VINORAGE WINE CELLAR
– AND YOUR WINE COLLECTION!

CONTACT

VINORAGE™

Terndrupvej 69, DK-9460 Brovst
kontakt@vinorage.dk
+45 28 97 95 23
+45 51 89 51 13